

Indoor Water Conservation Tips

General

- Never pour water down the drain when there may be another use for it. Use it to water your indoor plants or garden.
- Repair dripping faucets by replacing washers. One drop per second wastes 2,700 gallons of water per year!
- Check all plumbing for leaks. Have leaks repaired by a plumber.
- Retrofit all household faucets by installing aerators with flow restrictors.
- Install an instant hot water heater on your sink.
- Insulate your water pipes to reduce heat loss and prevent them from breaking.
- Choose appliances that are more energy and water efficient.

Bathroom

- Consider purchasing a low-volume toilet that uses less than half the water of older models.
- Install a toilet displacement device to cut down on the amount of water needed to flush. Place a one-gallon plastic jug of water into the tank to displace toilet flow (do not use a brick, it may dissolve and loose pieces may cause damage to the internal parts). Be sure installation does not interfere with the operating parts.
- Replace your showerhead with an ultra-low-flow version.
- Place a bucket in the shower to catch excess water for watering plants.
- Avoid flushing the toilet unnecessarily. Dispose of tissues, insects, and other similar waste in the trash rather than the toilet.
- Avoid taking baths - take short showers - turn on water only to get wet and lather and then again to rinse off.
- Avoid letting the water run while brushing your teeth, washing your face, or shaving.



Kitchen

- Operate automatic dishwashers only when they are fully loaded. Use the "light wash" feature, if available, to use less water.
- Hand wash dishes by filling two containers - one with soapy water and the other with rinse water containing a small amount of chlorine bleach.
- Clean vegetables in a pan filled with water rather than running water from the tap.
- Start a compost pile as an alternate method of



disposing of food waste or simply dispose of food in the garbage. (Kitchen sink disposals require a lot of water to operate properly).

- Store drinking water in the refrigerator. Do not let the tap run while you are waiting for water to cool.
- Avoid wasting water waiting for it to get hot. Capture it for other uses such as plant watering or heat it on the stove or in a microwave.
- Avoid rinsing dishes before placing them in the dishwasher; just remove large particles of food. (Most dishwashers can clean soiled dishes very well, so dishes do not have to be rinsed before washing)
- Avoid using running water to thaw meat or other frozen foods. Defrost food overnight in the refrigerator or use the defrost setting on your microwave oven.

Laundry



- Operate automatic clothes washers only when they are fully loaded or set the water level for the size of your load.

[Click here for Outdoor Water Saving Tips](#) (PAGE 4 Outdoor Water Saving Tips)

[Click here for Utility Billing Questions](http://cityofpacific.com/utilities.html) (<http://cityofpacific.com/utilities.html>)